



## USER GUIDE

**▲ WARNING:**  
CHOKING HAZARD - Small parts.  
Not for children under 3 yrs.



# TRICKS

## Wind up





Fig. 1



## Bind return

Wind string around your finger one time. Then finish winding yoyo. Throw sleeper. Place finger in front of string. Catch yoyo back on the string by swinging the yoyo forward and around your finger. Pinch loop. Lower loop down towards yoyo. The yoyo will suddenly climb the string. Move *quick* and release loop before yoyo hits your hand!


(Fig. 1)

### Safety tip

Never aim your yoyo at people, pets, or breakables. Check to make sure your playing area is safe before throwing and keep yoyos away from children under 3 years old. Play like a pro, change your string often.


## Finger grind

Throw a "break away". Pop yoyo up and land on finger. Point finger slightly down for best results. With practice you can "grind" for 4-5 seconds.



## Arm grind

Throw a "break away". Pop yoyo up and land on finger. Tip finger up and allow yoyo to walk up your arm.




## RESPONSE

If your Yo-Yo starts to lose it's tight bind response change the rubber response pads.


### To replace response:

1. peel up worn pad
2. peel paper from new pad and stick back in yoyo half



## String basics

MAKE A SLIP-KNOT LIKE THIS




Place slip-knot on middle finger here

## New string

First untwist string.

Place whole yoyo in loop, do not take yoyo apart to replace string.



IMPORTANT NOTE: ALWAYS PUT STRING ON LAST!

## String length

String length may be adjusted by the user. Adjust the string length by letting the yoyo hang to the ground and tie a new loop at belly button height.

Trim the excess string, make a slip-knot and get ready for action.

