



User Guide

▲ WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 yrs.



Tricks

Wind up






Fig. 1



Finger grind


Throw a "break away". Pop yoyo up and land on finger. Point finger slightly down for best results. With practice you can "grind" for 4-5 seconds.



Bind return


Wind string around your finger one time. Then finish winding yoyo. Throw sleeper. Place finger in front of string. Catch yoyo back on the string by swinging the yoyo forward and around your finger. Pinch loop. Lower loop down towards yoyo. The yoyo will suddenly climb the string. Move quick and release loop before yoyo hits your hand!

(Fig. 1)




Arm grind

Throw a "break away". Pop yoyo up and land on finger. Tip finger up and allow yoyo to walk up your arm.



Parts are Interchangeable with F.A.S.T.® Offstring®




Response

If your Yo-Yo starts to lose it's tight bind response change the rubber response pads.

To replace response:

1. peel up worn pad
2. peel paper from new pad and stick back in yo-yo half



String length


String length may be adjusted by the user. Adjust the string length by letting the yo-yo hang to the ground and tie a new loop at belly button height.

Trim the excess string, make a slip-knot and get ready for action.



String basics

MAKE A SLIP-KNOT LIKE THIS




Place slip-knot on middle finger here

New string

First untwist string.

Place whole yo-yo in loop, do not take yo-yo apart to replace string.

IMPORTANT NOTE: ALWAYS PUT STRING ON LAST!



Safety tip

Never aim your yo-yo at people, pets, or breakables. Check to make sure your playing area is safe before throwing and keep yo-yos away from children under 3 years old. Play like a pro, change your string often.